

Issued by NMI Certin B.V.,  
designated and notified by the Netherlands to perform tasks with respect to  
conformity modules mentioned in article 17 of Directive 2014/32/EU, after  
having established that the Measuring instrument meets the applicable  
requirements of Directive 2014/32/EU, to:

Manufacturer NRKsM  
Pondweg 7  
2153 PK Nieuw-Vennep  
The Netherlands

Measuring instrument A static **Active Electrical Energy Meter**  
Type : Ex9EMS 3P 4M CT 2T, Ex9EMS 3P 4M  
CT MB 2T and Ex9EMS 3P 4M CT MO  
2T

Manufacturer's mark or name : NRKsM  
Reference voltage : 3x230/400 V  
Reference current : 1,5 A  
Destined for the measurement of : electrical energy, in a  
- three-phase four-wire network  
- three-phase three-wire network  
- single-phase two-wire network  
Accuracy class : C  
Environment classes : M1 / E2  
Temperature range : -25 °C / +70 °C

Further properties are described in the annexes:  
- Description T11261 revision 0;  
- Documentation folder T11261-1.

Valid until 19 January 2028

Issuing Authority **NMI Certin B.V., Notified Body number 0122**  
19 January 2018



C. Oosterman  
Head Certification Board

**NMI Certin B.V.**  
Hugo de Grootplein 1  
3314 EG Dordrecht  
The Netherlands  
T +31 78 6332332  
certin@nmi.nl  
www.nmi.nl

This document is issued under the provision  
that no liability is accepted and that the  
manufacturer shall indemnify third-party  
liability.

The designation of NMI Certin B.V. as Notified  
Body can be verified at  
[http://ec.europa.eu/growth/tools-  
databases/nando/](http://ec.europa.eu/growth/tools-databases/nando/)

Reproduction of the complete  
document only is permitted.

## 1 General information about the instrument

All properties of the static active electrical energy meter, whether mentioned or not, shall not be in conflict with the legislation.

### 1.1 Essential parts

Description	Document	Remarks
measuring sensor	11261/0-06	
printed circuit board	11261/0-11 or 11261/0-12 11261/0-13, 11261/0-14 or 11261/0-15	All parts of the printed circuit boards are essential, except the components which are related to parts as described in paragraph 1.4 or 1.6.

### 1.2 Essential characteristics

- 1.2.1 See EU-type examination certificate T11261 revision 0 and the characteristics mentioned below.
- 1.2.2 Approved meter types : Ex9EMS 3P 4M CT 2T, Ex9EMS 3P 4M CT MB 2T and Ex9EMS 3P 4M CT MO 2T  
 An explanation of all type designations is presented in document no. 11261/0-02.
- 1.2.3 Frequency : 50 Hz
- 1.2.4 Meter constant : 10.000 imp./kWh
- 1.2.5 Number of registers : 4
- 1.2.6 Error messages : An overview of all error codes is presented in chapter 8.1 of the user manual (document no. 11261/0-03)
- 1.2.7 Phase sequence : the meter is not sensitive to the direction of the applied phase sequence.
- 1.2.8 Export energy : the meter is capable of measuring energy in 2 directions.  
 The meter can also be used with 2 phases loaded with import energy and 1 phase loaded with export energy.
- 1.2.9 Software specification (refer to WELMEC 7.2):
- Software type P;
  - Risk Class C;
  - Extensions L, D, S and T are not applicable.

Software version	Identification number (checksum)	Remarks

Software version	Identification number (checksum)	Remarks
1.14 or 1.15 or 1.16 or 1.17 or 1.18 or 1.19 or 1.20 or 2.18 or 2.19	009C78FA 009D1585 009C8616 009F3097 009F7302 009D1081 or 009E8081 00970C09 0D010556 0D104797	The checksum is displayed after pressing the left arrow button 4 times.

### 1.3 Essential shapes

- 1.3.1 The nameplate is bearing at least, good legible, the information as mentioned in the regulations on energy meters. An example of the markings is shown in document no. 11261/0-05.
- 1.3.2 Sealing: see chapter 2.
- 1.3.3 The registration observation is executed by means of a LED.

### 1.4 Conditional parts

- 1.4.1 Terminal block  
 The connections for the current cables on the terminal block have a diameter of at least 7 mm. The cables are connected with the terminal block via one screw. See document no. 11261/0-09.  
 For 3-phase 3-wire connections, a bridge has to be made between pin 13 and 17, as indicated on the markings and in the user manual. See document no. 11261/0-04.
- 1.4.2 Housing  
 The meter has got a dustproof housing, which has sufficient tensile strength. The cover is made of synthetic material. Examples of the housing are presented in document no. 11261/0-01 and 11261/0-07 or 11261/0-08.
- 1.4.3 Terminal cover  
 The terminal cover is made of synthetic material.
- 1.4.4 Register  
 The quantity of measured energy is presented by means of a display with at least 8 elements. The way of presentation is described in chapter 7 of the user manual (document no. 11261/0-03) or document no. 11261/0-04 (connection diagram).
- 1.4.5 Tariff control  
 When the meter is provided with more than one register, a tariff control is available by means of tariff inputs, whereby the EMC-requirements are fulfilled as described in Annex V of Directive 2014/32/EU.



# Description

Number **T11261** revision 0  
Project number 1901797  
Page 3 of 3

- 1.4.6 **Optical communication**  
The meter is provided with optical communication. Via the communication no legally relevant data can be altered.
- 1.4.7 **M-Bus (optional)**  
The meter may be equipped with M-Bus communication. Via the communication no legally relevant data can be altered.
- 1.4.8 **Modbus (optional)**  
The meter may be equipped with Modbus communication. Via the communication no legally relevant data can be altered.
- 1.4.9 **Copper slice at the buttons (optional)**  
The meter may be equipped with copper slices at the buttons in order to promote the sensitivity. See document no. 11261/0-11.

## **1.5 Conditional characteristics**

- 1.5.1 **Maximum current:**  
smaller than or equal to 6 A, and at least 1,2 times higher than the reference current.
- 1.5.2 **Minimum current:** 0,015 A

## **1.6 Non-essential parts**

- 1.6.1 **Pulse output**

## **2 Seals**

The meter casing is sealed with a sealing sticker.  
An example of the sealing is presented in document no. 11261/0-10.

## **3 Conditions for conformity assessment according to module D or F**

The influence factors for temperature, frequency and voltage, which are necessary to perform the conformity assessment according to module D or F, are presented in Annex 1, belonging to this EU-type examination certificate.  
Based on the WELMEC 11.1, section 2.5.6, the sum of the square values is presented.

## Influence factors for temperature, frequency and voltage

During the type approval examination the influence factors for temperature, frequency and voltage are determined per load point. The values depicted in the table below present the root sum square values per load point, determined via the following formula:

$$\delta e(T, U, f) = \sqrt{\delta e^2(T, I, \cos \varphi) + \delta e^2(U, I, \cos \varphi) + \delta e^2(f, I, \cos \varphi)}$$

with:

- $\delta e(T, I, \cos \varphi)$  = the additional percentage error due to the variation of the temperature at a certain load;
- $\delta e(U, I, \cos \varphi)$  = the additional percentage error due to the variation of the voltage at the same load;
- $\delta e(f, I, \cos \varphi)$  = the additional percentage error due to the variation of the frequency at the same load.

Current	Power factor	-40°C [%]	-25°C [%]	-10°C [%]	+5°C [%]	+23°C [%]	+40°C [%]	+55°C [%]	+70°C [%]
I <sub>min</sub>	1	0,5	0,4	0,2	0,1	0,2	0,4	0,7	0,5
I <sub>tr</sub>	1	0,5	0,4	0,2	0,0	0,2	0,5	0,7	0,5
	0,5 ind.	0,5	0,4	0,2	0,1	0,2	0,4	0,7	0,5
	0,8 cap.	0,5	0,4	0,2	0,1	0,2	0,5	0,7	0,5
I <sub>tr</sub> phase R	1	0,4	0,3	0,2	0,0	0,2	0,3	0,5	0,4
	0,5 ind.	0,5	0,3	0,2	0,0	0,2	0,3	0,5	0,5
I <sub>tr</sub> phase S	1	0,4	0,4	0,2	0,0	0,2	0,5	0,7	0,4
	0,5 ind.	0,5	0,4	0,2	0,0	0,2	0,5	0,7	0,5
I <sub>tr</sub> phase T	1	0,7	0,5	0,3	0,0	0,3	0,6	0,9	0,7
	0,5 ind.	0,7	0,5	0,2	0,0	0,3	0,5	0,8	0,7
20 I <sub>tr</sub>	1	0,5	0,4	0,2	0,0	0,2	0,5	0,7	0,5
	0,5 ind.	0,5	0,4	0,2	0,0	0,2	0,5	0,7	0,5
	0,8 cap.	0,4	0,3	0,1	0,0	0,3	0,5	0,8	0,4
20 I <sub>tr</sub> phase R	1	0,4	0,3	0,2	0,0	0,2	0,3	0,5	0,4
	0,5 ind.	0,4	0,3	0,1	0,0	0,2	0,4	0,6	0,4
20 I <sub>tr</sub> phase S	1	0,5	0,4	0,2	0,0	0,2	0,5	0,7	0,5
	0,5 ind.	0,5	0,3	0,2	0,0	0,3	0,5	0,8	0,5
20 I <sub>tr</sub> phase T	1	0,7	0,4	0,2	0,0	0,3	0,6	0,9	0,7
	0,5 ind.	0,6	0,4	0,2	0,0	0,3	0,6	0,9	0,6
I <sub>max</sub>	1	0,5	0,3	0,2	0,0	0,3	0,5	0,7	0,5
	0,5 ind.	0,5	0,3	0,2	0,0	0,3	0,5	0,7	0,5
	0,8 cap.	0,5	0,3	0,2	0,0	0,3	0,5	0,7	0,5
I <sub>max</sub> phase R	1	0,4	0,2	0,1	0,0	0,2	0,4	0,6	0,4
	0,5 ind.	0,4	0,3	0,1	0,0	0,2	0,4	0,6	0,4
I <sub>max</sub> phase S	1	0,4	0,3	0,2	0,0	0,2	0,5	0,7	0,4
	0,5 ind.	0,5	0,4	0,2	0,0	0,3	0,5	0,8	0,5
I <sub>max</sub> phase T	1	0,7	0,4	0,2	0,0	0,3	0,6	0,9	0,7
	0,5 ind.	0,7	0,4	0,2	0,0	0,3	0,6	0,6	0,7